

How To Change a Power Cord

What You will Need:

- Philips Head Screw Driver
- Step Ladder

Important: Unplug the Sauna before starting. Make sure the new power cord outlet plug matches the old plug.


Step 1: Using the step ladder go to the roof of the Sauna, locate the power cord. Most power cords can be found in the left upper corner of the Sauna.

Step 2: Follow the power cord along the inside roof wall of the Sauna to the power supply found under a mesh cut out in the roof. Unscrew enough roof panels to expose the power supply and power cord connectors.

Step 3: Once exposed follow the power cord to where a large molex connector meets the power supply. Unconnect the molex connector to release the power cord from the power supply and Sauna.

Step 4: Finish removing the power cord by unscrewing all the plastic tabs holding the power cord to the Sauna. Take any new power cord and reverse the above steps. Making sure the connectors between the power cord and power supply are firmly connected.

Below are images illustrating the above process.



How To Change a Power Cord